

## Spares for NAVIN Grinding Mills 1A

Base Frame	NC_GM_1A_001
Bottom hopper	NC_GM_1A_002
Standing plate/Box	NC_GM_1A_003
Bearing block	NC_GM_1A_004
Bearing	NC_GM_1A_005
Oil Lid	NC_GM_1A_006
Shaft	NC_GM_1A_007
Toe For Spindle	NC_GM_1A_008
Driving Plate	NC_GM_1A_009
Cam	NC_GM_1A_010
Springs	NC_GM_1A_011
Front/Dome	NC_GM_1A_012
Thrust block	NC_GM_1A_013
Click Holder	NC_GM_1A_014
Click	NC_GM_1A_015
Regulating wheel	NC_GM_1A_016
Standard- with arm/bend leg	NC_GM_1A_017
Shaker arm	NC_GM_1A_018
Spacer for shaker arm	NC_GM_1A_019
Collar	NC_GM_1A_020
Shaker rod bearing/jigger plate/leg bearing	NC_GM_1A_021
Jigger rod	NC_GM_1A_022
Tongue	NC_GM_1A_023
Standard-plain/ straight leg	NC_GM_1A_024
Shoe	NC_GM_1A_025
Shoe pin	NC_GM_1A_026
Shoe link/bay link	NC_GM_1A_027
Bridge and rod	NC_GM_1A_028
Top hopper	NC_GM_1A_029
Tin hopper	NC_GM_1A_030
MS stand	NC_GM_1A_031
Cast iron stand	NC_GM_1A_032
Flywheel	NC_GM_1A_033
Driving pulley	NC_GM_1A_034

## Spares for NAVIN Grinding Mills 2A

Base Frame	NC_GM_2A_001
Bottom hopper	NC_GM_2A_002
Standing plate/Box	NC_GM_2A_003
Bearing block	NC_GM_2A_004
Bearing	NC_GM_2A_005
Oil Lid	NC_GM_2A_006
Shaft	NC_GM_2A_007
Toe For Spindle	NC_GM_2A_008
Driving Plate	NC_GM_2A_009
Cam	NC_GM_2A_010
Springs	NC_GM_2A_011
Front/Dome	NC_GM_2A_012
Thrust block	NC_GM_2A_013
Click Holder	NC_GM_2A_014
Click	NC_GM_2A_015
Regulating wheel	NC_GM_2A_016
Standard- with arm/bend leg	NC_GM_2A_017
Shaker arm	NC_GM_2A_018
Spacer for shaker arm	NC_GM_2A_019
Collar	NC_GM_2A_020
Shaker rod bearing/jigger plate/leg bearing	NC_GM_2A_021
Jigger rod	NC_GM_2A_022
Tongue	NC_GM_2A_023
Standard-plain/ straight leg	NC_GM_2A_024
Shoe	NC_GM_2A_025
Shoe pin	NC_GM_2A_026
Shoe link/bay link	NC_GM_2A_027
Bridge and rod	NC_GM_2A_028
Top hopper	NC_GM_2A_029
Tin hopper	NC_GM_2A_030
MS stand	NC_GM_2A_031
Cast iron stand	NC_GM_2A_032
Flywheel	NC_GM_2A_033
Driving pulley	NC_GM_2A_034

## Spares for NAVIN Grinding Mills 3A

Base Frame	NC_GM_3A_001
Bottom hopper	NC_GM_3A_002
Standing plate/Box	NC_GM_3A_003
Bearing block	NC_GM_3A_004
Bearing	NC_GM_3A_005
Oil Lid	NC_GM_3A_006
Shaft	NC_GM_3A_007
Toe For Spindle	NC_GM_3A_008
Driving Plate	NC_GM_3A_009
Cam	NC_GM_3A_010
Springs	NC_GM_3A_011
Front/Dome	NC_GM_3A_012
Thrust block	NC_GM_3A_013
Click Holder	NC_GM_3A_014
Click	NC_GM_3A_015
Regulating wheel	NC_GM_3A_016
Standard- with arm/bend leg	NC_GM_3A_017
Shaker arm	NC_GM_3A_018
Spacer for shaker arm	NC_GM_3A_019
Collar	NC_GM_3A_020
Shaker rod bearing/jigger plate/leg bearing	NC_GM_3A_021
Jigger rod	NC_GM_3A_022
Tongue	NC_GM_3A_023
Standard-plain/ straight leg	NC_GM_3A_024
Shoe	NC_GM_3A_025
Shoe pin	NC_GM_3A_026
Shoe link/bay link	NC_GM_3A_027
Bridge and rod	NC_GM_3A_028
Top hopper	NC_GM_3A_029
Tin hopper	NC_GM_3A_030
MS stand	NC_GM_3A_031
Cast iron stand	NC_GM_3A_032
Flywheel	NC_GM_3A_033
Driving pulley	NC_GM_3A_034