

Spares for NAVIN Rice Hullers & Polishers No.1

Cover	NC_RHP_N1_001
Frame	NC_RHP_N1_002
Hopper Seat Square	NC_RHP_N1_003
A 13 Bracket	NC_RHP_N1_004
O 14 Bracket	NC_RHP_N1_005
Cover Clamp	NC_RHP_N1_006
Cylinder A	NC_RHP_N1_007
Cylinder B	NC_RHP_N1_008
R.H.Screen	NC_RHP_N1_009
Polisher Screen	NC_RHP_N1_010
Blade	NC_RHP_N1_011
Holder	NC_RHP_N1_012
Ball Bearing Block	NC_RHP_N1_013
Ball Bearing Sleeve	NC_RHP_N1_014
Ball Bearing 6209K	NC_RHP_N1_015
Huller Nut	NC_RHP_N1_016
Huller Shaft, Key, Nut	NC_RHP_N1_017
Engine Pulley 12 x 5	NC_RHP_N1_018
Engine Pulley 12 x 6	NC_RHP_N1_019
Cylinder Shaft - No.7	NC_RHP_N1_020

Spares for NAVIN Rice Hullers & Polishers No.7

Cover	NC_RHP_N7_001
Frame	NC_RHP_N7_002
Hopper Seat Square	NC_RHP_N7_003
A 13 Bracket	NC_RHP_N7_004
O 14 Bracket	NC_RHP_N7_005
Cover Clamp	NC_RHP_N7_006
Cylinder A	NC_RHP_N7_007
Cylinder B	NC_RHP_N7_008
R.H.Screen	NC_RHP_N7_009
Polisher Screen	NC_RHP_N7_010
Blade	NC_RHP_N7_011
Holder	NC_RHP_N7_012
Ball Bearing Block	NC_RHP_N7_013
Ball Bearing Sleeve	NC_RHP_N7_014
Ball Bearing 6209K	NC_RHP_N7_015
Huller Nut	NC_RHP_N7_016
Huller Shaft, Key, Nut	NC_RHP_N7_017
Engine Pulley 12 x 5	NC_RHP_N7_018
Engine Pulley 12 x 6	NC_RHP_N7_019
Cylinder Shaft - No.7	NC_RHP_N7_020